

Compatible eKEY® App Devices

The Supra eKEY app is rigorously tested on popular models of smartphones and tablets to determine its compatibility with Android™, Apple®, and BlackBerry® devices. This list shows some of the specific devices tested. Check with your MLS or Board regarding which keyboxes are currently being used.



Android™	Apple®	BlackBerry®																						
<p>Requirements:</p> <ul style="list-style-type: none"> • Phones or tablets with OS 2.1 or newer • A cellular data plan • A current eKEY application downloaded on the device from the Google Play™ Store app 	<p>Requirements:</p> <ul style="list-style-type: none"> • Phones or tablets with iOS 5.1.1 or newer • A cellular data plan • A current eKEY application downloaded on the device from App Store™ 	<p>Requirements:</p> <ul style="list-style-type: none"> • Phones or tablets with OS 5 or newer, except the BlackBerry 10 • A cellular data plan • A current eKEY application downloaded on the device from BlackBerry App World™ 																						
<p>A Supra® eKEY Fob is required to open the classic iBox device. A fob is not required to open the iBox BT or iBox BT LE.</p> <p>Examples of Compatible Phones:</p> <table border="0"> <tr> <td>BlackBerry® Priv™</td> <td>LG® Enlighten™ Intuition™ Optimus™ Revolution™ Thrill™ Vortex™</td> </tr> <tr> <td>Google® Nexus™ 7 Nexus One™ Nexus S™</td> <td></td> </tr> <tr> <td>HTC™ Aria™ Desire Eris EVO™ 4G EVO 3D Hero™ Incredible 2 Incredible Sense Thunderbolt™ Touch 2 Wildfire™</td> <td>Motorola™ Atrix 2 Bionic Droid 2 Droid X Razr Razr M</td> </tr> <tr> <td></td> <td>Samsung™ Charge Epic™ Galaxy S™5, S4, S3, S2, & S Galaxy Note™4, 3, & 2 Moment</td> </tr> </table>	BlackBerry® Priv™	LG® Enlighten™ Intuition™ Optimus™ Revolution™ Thrill™ Vortex™	Google® Nexus™ 7 Nexus One™ Nexus S™		HTC™ Aria™ Desire Eris EVO™ 4G EVO 3D Hero™ Incredible 2 Incredible Sense Thunderbolt™ Touch 2 Wildfire™	Motorola™ Atrix 2 Bionic Droid 2 Droid X Razr Razr M		Samsung™ Charge Epic™ Galaxy S™5, S4, S3, S2, & S Galaxy Note™4, 3, & 2 Moment	<p>Supra eKEY Fob or Adapter is not needed for iBox BTLE (Bluetooth 4.0) if the Apple products are:</p> <ul style="list-style-type: none"> • iPhone models 4s or newer • Retina iPad model or newer • iPad Mini <p>Use a Supra eKEY Fob: For iBox BT LE devices with older Apple products or when opening an iBox BT (Bluetooth 2.0) device.</p> <ul style="list-style-type: none"> • iPhone models 4 and older • iPad 2 models and older • iBox BT device <p>Examples of Compatible Phones:</p> <table border="0"> <tr> <td>iPhone® 6s, 6, & 6 Plus 5s, 5c, & 5 4s & 4 3GS</td> <td>iPad® iPad Mini iPad 4th Gen. iPad 3rd Gen. iPad 2G</td> </tr> </table>	iPhone® 6s, 6, & 6 Plus 5s, 5c, & 5 4s & 4 3GS	iPad® iPad Mini iPad 4 th Gen. iPad 3 rd Gen. iPad 2G	<p>A Supra® eKEY Fob is required to open the classic iBox device. A fob is not required to open the iBox BT or iBox BT LE.</p> <p>Examples of Compatible Phones:</p> <table border="0"> <tr> <td>Bold™ 9930 9900 9790 9780 9700 9650 9000</td> <td>Curve™, cont'd 8530 8520 8350i 8330</td> </tr> <tr> <td></td> <td>Pearl 9100™</td> </tr> <tr> <td></td> <td>Storm™ Storm Storm 2</td> </tr> <tr> <td></td> <td>Style™ 9670</td> </tr> <tr> <td></td> <td>Torch™ 9800 9810 9850 9860</td> </tr> <tr> <td></td> <td>Tour™</td> </tr> </table> <p>NOTE: The BlackBerry 10 is not supported at this time.</p>	Bold™ 9930 9900 9790 9780 9700 9650 9000	Curve™, cont'd 8530 8520 8350i 8330		Pearl 9100™		Storm™ Storm Storm 2		Style™ 9670		Torch™ 9800 9810 9850 9860		Tour™
BlackBerry® Priv™	LG® Enlighten™ Intuition™ Optimus™ Revolution™ Thrill™ Vortex™																							
Google® Nexus™ 7 Nexus One™ Nexus S™																								
HTC™ Aria™ Desire Eris EVO™ 4G EVO 3D Hero™ Incredible 2 Incredible Sense Thunderbolt™ Touch 2 Wildfire™	Motorola™ Atrix 2 Bionic Droid 2 Droid X Razr Razr M																							
	Samsung™ Charge Epic™ Galaxy S™5, S4, S3, S2, & S Galaxy Note™4, 3, & 2 Moment																							
iPhone® 6s, 6, & 6 Plus 5s, 5c, & 5 4s & 4 3GS	iPad® iPad Mini iPad 4 th Gen. iPad 3 rd Gen. iPad 2G																							
Bold™ 9930 9900 9790 9780 9700 9650 9000	Curve™, cont'd 8530 8520 8350i 8330																							
	Pearl 9100™																							
	Storm™ Storm Storm 2																							
	Style™ 9670																							
	Torch™ 9800 9810 9850 9860																							
	Tour™																							

